



Install Instructions

1. Prime panel and frame on all sides to avoid moisture damage.
2. On all four sides, secure frame and drywall to adequate solid framing.
3. Make sure the frame is not twisted. Shimming may be required to maintain panel trueness.
4. Pre-fill large gaps between drywall and frame.
5. Set tape using paper tape only.
6. Use all-purpose compound or Durabond 45 or 90.
7. Finish as you would your taping.

Magnet panels are for wall application ONLY

Do NOT use Fiber Tape, Light Compound or Fast Setting Sandable 20, 45, or 90

Note:

This instruction sheet has been carefully drawn up to the best of our knowledge. We accept no liability for any mistakes, errors in standards or printing errors. In addition, technical modifications can result from the continuous further development, as well as from changes in data from material suppliers. Warranty is only provided on the product and not the install or application.

Last Revised: 2024-01-11

All Rights Reserved 2024 - Hammer Hill Diversified LTD.